
DOCUMENTATION CONTENTS

This document is composed by 2 section:

Section	Name	Description
1	Instruction	Main features and functions of PR010/T unit
2	Updating	Additional information and/or correction of Instruction inserted subsequently

ATTENTION

SACE PR010/T

test unit instructions



CONTENTS

1.	Safety notes	3
2.	Definitions, abbreviations	4
3.	General information	4
3.1	Introduction	4
3.2	Putting into service	5
3.3	General description	5
4.	Functions	6
4.1	Test Functions	6
4.1.1	Trip test	6
4.1.2	Protection functions test	6
4.1.3	Communication functions test	7
4.2	Programming function	7
4.3	Parameter reading function	7
4.4	Protection unit interface	8
4.5	PC interface	8
4.6	Test report	8
4.7	Special functions	10
5.	Software	10
5.1	Description	10
5.1.1	Report downloading	11
5.1.2	Test unit configuration	11
5.1.3	Software updating	11
5.2	Communication with PC	11
5.2.1	SW updating procedure	12
5.2.2	Test report downloading procedure	13
5.2.3	Test report erasing	14
5.3	Protection unit	14

6.	Technical specifications	14
6.1	User interface	14
6.2	Power supply	14
6.3	Inputs/Outputs	15
6.4	Mechanical specifications	16
6.5	Standard equipment	16
6.6	Applicable standards	17
6.7	Error messages and troubleshooting table	17
6.8	Notes	20

APPENDIX

1. Safety notes



WARNING

This symbol indicates information about procedures or situations that may cause injury to personnel, damage to the unit or financial loss.



WARNING

Carefully read the entire contents of this handbook. Damage resulting from failure to comply with the instructions effectively invalidates the terms of guarantee. The manufacturer declines all liability for damage to the unit caused by incorrect or improper usage.

ABB SACE also declines all liability for any ensuing damage or injury. Do not use the unit in damp or wet environments.

If in doubt about the safety of the unit, take it out of service to prevent inadvertent usage.

The unit's safety may be impaired if:

1. the unit shows visible signs of damage
2. the unit does not work
3. the unit is stored for a long period or has incurred damage during shipment.

Do not switch on the unit immediately after having transferred it from a hot environment to a cold one. Water condensation could damage or destroy the unit. Wait until the unit adapts to the new ambient temperature before switching it on.

Never leave discharged batteries inside the unit since the battery fluid may leak and damage the unit.

Do not use abrasive detergents, petrol or alcohol etc. to clean the unit, since these products may damage the unit's surface.

2. Definitions, abbreviations

Abbreviation	Description
CB	Circuit Breaker (for example: ABB SACE Emax and Isomax)
DUT	Device Under Test
HW	Hardware: the physical and electronic components that make up the device.
Password	Secret password which denies unauthorised access to certain SACE PR010/T functions.
PC	Personal Computer
Release	Protection unit otherwise known as a protection release.
SW	Software: the programs used by the microprocessors to execute a set of programmed functions/tasks.
CT	Current transformer
Trip test	Special test designed to trip the CB
TT1	ABB SACE trip test unit for use with some releases.

3. General information

3.1 Introduction

The SACE PR010/T unit is an instrument capable of performing the functions of testing, programming and reading parameters for the protection units equipping ABB SACE low-voltage circuit-breakers. For the specific functions, refer to the respective protection unit. All of the functions mentioned may be carried out "on board" by connecting the SACE PR010/T unit to the front connector on the protection unit. Two different types of test are available: automatic and manual. It is also possible to perform the trip test through the SACE TT1 unit.

By connecting to a PC (using the disc supplied by ABB SACE, or SW downloaded from the ABB Internet site) it is possible to upgrade the software of the SACE PR010/T unit. The unit can also save important test results, which may then be downloaded to a PC following a request for a test report.


The SACE PR010/T test unit is a portable instrument operated by rechargeable batteries and/or an external power supply.

3.2 Putting into service

To put the SACE PR010/T unit into service, proceed as follows:

- Fit the batteries in the corresponding battery compartment (13), taking care to check the polarity first.
- Connect the external power supply to the 12 Vdc outlet (11).
- Wait for the batteries to charge (when the PR010/T unit is switched off, the battery charge status bar is stationary). Even when the batteries are discharged, the PR010/T unit can still operate if connected to the external power supply.

3.3 General description



1. Cable connector for connection to circuit breaker protection unit
2. Backlit LCD display (4 x 20-character lines) to display messages and test results
3. Cable connector for connection to Personal Computer
4. Green/red unit status indicator led (power on - stand-by)
5. Stop test or special functions key
6. Return/cancel key
7. Arrow selection and setting keys
8. Alphanumeric setting and control keyboard
9. Confirm key
10. Red battery charge status indicator led
11. External power supply socket
12. Sliding unit on/off switch
13. Battery compartment
14. SACE PR010/T unit serial number

4. Functions

4.1 Test Functions

The SACE PR010/T test unit tests protection units by monitoring both their HW and SW components. In particular, the unit performs the following tests:

- Trip test: by means of SACE TT1 unit
- Protection functions test
- Communication functions test

4.1.1 Trip test

The trip test tests the operation of the microprocessor, release and opening solenoid chain.

The trip test may also be performed with the circuit breaker on.

This test is performed by means of SACE TT1 unit.


 **WARNING**
For safety reasons, the current flow inside the circuit breaker must be zero during testing.

For this reason, the current flow is automatically monitored before testing and registered as zero if the reading detected is below a preset value.

4.1.2 Protection functions test

The device under test is powered up and the fault condition for the protection function to be tested is simulated. In case of units provided with internal bus, the internal status of the protections (alarm and trip messages etc.) may also be monitored.

In case of certain releases, the type of release and circuit breaker and the rated current of the CTs installed are also automatically identified.

 **WARNING**
For safety reasons, protection function tests must only be performed with the circuit breaker off.

These tests may be performed in both automatic and manual mode.

- **Automatic mode:** releases equipped with internal bus (see electrical diagrams in the Technical Catalogue) are automatically tested. The PR010/T unit is in fact capable of self-learning the protection parameter settings and, based on these parameters, of generating a fault signal for each function in order to test the timing. In the event of an anomaly, the type of error detected is indicated by the corresponding message (threshold or timing error). This sequence is automatically repeated on all protection unit functions. Testing may be interrupted at any time using the STOP button, thereby restoring the original conditions/settings of the

protection unit prior to testing. In the case of releases not equipped with internal bus, the user must preset the protections before testing.

- **Manual mode:** this test may be performed on any type of protection. In this case, the user must set all the protection parameters before testing. During manual testing, the user selects the type of device to be tested from a menu, whereupon device protection functions and thresholds are displayed so that the user can set the required test parameters. If the user selects an intermediate threshold in relation to those actually available, the SACE PR010/T test unit will automatically convert it to the highest one. The fault may be simulated either separately or simultaneously on any combination of phases L1, L2, L3 and NE.

4.1.3 Communication functions test

The SACE PR010/T test unit can also test the serial communication circuits of the protection releases.

4.2 Programming function

Using the SACE PR010/T test unit, the type of releases with internal bus mounted on ABB SACE low voltage circuit breakers can be programmed.

You can also program all the protection function parameters (threshold, curve, interlock parameters etc.). The parameter-programming function does not interrupt the normal operation of the protection unit, although parameters cannot be set if a timing alarm is pending.

The SACE PR010/T test unit will not set parameters outside the permitted range.

A message is displayed at the end of programming to indicate that the parameters have been successfully programmed.

Each operating parameter modified must first be confirmed before it is saved. In the event of a programming error, simply press the ESC key to cancel the last entry/action.

4.3 Parameter reading function

If the SACE PR010/T test unit is connected to releases with internal bus, it is possible to read the main parameters of the protection units.

At the user's express request and, subject to availability, the SACE PR010/T test unit can provide information about the following:

- protection status (thresholds, alarms, trips etc.)
- circuit breaker status (number of operations, contact wear etc.)
- phase, neutral and earth fault current readings
- serial number and SW release (available on the "Information" menu page).

NOTE: The parameter reading function is permanently available, irrespective of the protections and CB status.

4.4 Protection unit interface

The SACE PR010/T test unit can perform all the operations described above without extracting the protection units from the circuit breakers. The test unit (connector 1) is connected to the releases by a cable fitted with a special connector. The SACE PR010/T test unit is connected to the various types of release using the specific cables for each type of release.

4.5 PC interface

The SACE PR010/T test unit is fitted with a connector (3) for connection to a PC (standard RS232 serial port). This interface is used to update the unit's software and download test reports.

4.6 Test report

The SACE PR010/T test unit can save the main test results in order to compile a test report. The unit can store up to five test reports. After the test reports have been downloaded in the PC it is advisable to delete them from the PR010/T so as to have enough free memory available for new reports. The SACE PR010/T test unit saves data even when disconnected from the power supply. Test results are downloaded to a PC when the user requests a test report. The test report contains the following information, which is automatically supplied by the unit or manually entered by the user:

- unit serial number (Sr. Nr.)	Manually entered by user
- date and time of test	
- operator name	
- type of unit tested	Automatically supplied for releases with internal bus only.

The following information is automatically indicated for each protection function tested:

- type of protection
- threshold selected
- curve selected
- phase tested
- test current
- estimated trip time
- measured trip time
- test results.

Test report example:

TEST REPORT WITH SACE PR010/T	
SW Version: 3.2	

Date:	03/05/00
Hour:	13:55
Operator:	Belometti
Relay S.Nr.:	M0047C03B
Relay type:	PR112
Relay version:	LSIG
CB type:	E1B800
CT rated current:	250 A
Neutral:	50%


Protection:	L
Threshold [In]:	0.400
Curve [s]:	3.00
Curve type:	$t=k/i^2$
Tested phase(s):	L1
Fault current [In]:	2.40
Expected time [s]:	0.750
Measured time [s]:	0.758
Test result:	OK
Protection:	S
Threshold [In]:	0.800
Curve [s]:	0.35
Curve type:	$t=k/i^2$
Tested phase(s):	L1
Fault current [In]:	1.60
Expected time [s]:	13.668
Measured time [s]:	11.984
Test result:	OK
Protection:	I
Threshold [In]:	4.000
Curve [s]:	inst
Curve type:	$t=k$
Tested phase(s):	L1
Fault current [In]:	8.00
Expected time [s]:	0.060
Measured time [s]:	0.016
Test result:	OK
Protection:	G
Threshold [In]:	0.400
Curve [s]:	0.10
Curve type:	$t=k/i^2$
Tested phase(s):	--
Fault current [In]:	1.00
Expected time [s]:	0.320
Measured time [s]:	0.314
Test result:	OK

4.7 Special functions

- With regard to the setting of the protection parameters it is possible to carry out several tests using different thresholds and curves to identify the optimum program for the circuit breaker/ installation.
- The test unit can memorise a special "frequent use" program for each of the protection units that may be electronically programmed (Define default).
- The manual test function also enables a general current to be introduced into the release in order to test the trip time (a particularly useful function for selectivity studies between two or more circuit breakers).

5. Software

5.1 Description



When the SACE PR010/T test unit is first switched on, it runs an initialisation test. If the test result is successful, the software version and battery charge status are displayed on the screen.

To open one of the sub-menus from the main menu, position the cursor using the

↓ or ↑ keys and press “Enter”.

To return to the main menu, press “ESC”.

The moving ■ sequence indicates that the test unit is busy, so you must wait until it has finished.

Sub-menu 1. "Operation mode" of the main menu is different for each type of protection unit (see "Operation mode menu tree").

Sub-menus 2. "Report download", 3. "PR010/T Config." and 4. "SW updating" are the same for all the protection units.

5.1.1 Report downloading

The SACE PR010/T test unit can download a test report onto a PC which contains all the information indicated under the heading "Test report".

5.1.2 Test unit configuration

The test unit configuration can be customized.

You can define a password (Define password) to use to access the testing and programming stages, to adjust brightness and contrast, and to select the language of your choice (default password: 00000).

If, after specifying a new password, you want to restore the default setting, you need to zero the password; to do so, select the "Reset password" item and notify ABB SACE of the code displayed (e.g. CODE = 63795).

ABB SACE will provide an unlock code to input on the same page (PLEASE INSERT RESET CODE-----) which enables you to reset the PR010/T with the default password (00000).

N.B. The unlock code can only be used for one password zeroing operation; for any subsequent password zeroing operations, you must go to the "Reset password" page again and notify ABB SACE of the new code it displays (e.g. CODE = 83922) in order to obtain the new unlock code.

You can also perform a test on the unit by selecting the "Test" menu.

The software is self-explanatory; simply follow the instructions that appear on the screen.

5.1.3 Software updating

The software installed on the SACE PR010/T test unit may be upgraded simply by connecting it to a PC and following the procedure described below in the section "Communication with PC".

5.2 Communication with PC

Using the "SD-TU Interface" software provided it is possible to update the SACE PR010/T unit, customizing the list of devices available for the test.

To install the software, just run the application "SD-TU Interface xxx.msi". The steps necessary for updating the test unit software are listed below.

Further explanations on the use of the "SD-TU Interface" software can be found in the software's own on-line help.

5.2.1 SW updating procedure

1. Switch on the SACE PR010/T test unit.
2. Connect the SACE PR010/T test unit (connector 3) to one of the PC's serial ports (COM1... COM4) using the cable supplied.
3. Run the "SD-TU Interface.exe" program.
4. From the list of devices that appears in the "Device selection" window on the left of the screen, use the mouse (holding down the left key) to select the device you want, dragging it into the "Device" window that appears on the right.
5. Repeat the selection operation indicated in point 4 for all the devices you want to insert (when the memory available is exhausted this is indicated with the message "PR010/T memory completely filled!!").
6. Select Program/From configuration on the PR010/T menu.
7. Now go to the PR010/T unit and select the 4.Update SW menu from the main menu. This message will appear:
'Update SW'
'ENTER to confirm'
8. Press ENTER on the SACE PR010/T unit to display the following message:
'Waiting SW update'
9. Before one minute elapses, press OK in the window displayed on the PC. The SACE PR010/T unit will now display the message:
'SW Updating in progress'
accompanied by a progressive status bar indicating the download time remaining. The maximum duration of the procedure may be several minutes, depending on the number of devices selected; the "programming status" bar is displayed on the PC monitor in the "Program PR010/T" window, indicating how the updating is proceeding. If the file is successfully downloaded, the SACE PR010/T unit will display the following message:
"End SW updating"
"SW Ver. X.X"
"Press ESC to restart"
while the PC will display the message:
"PR010/T successfully programmed"
Press ESC on the SACE PR010/T unit to restart the unit with the new software version. Close the PC application.
10. If the file is not successfully downloaded, the SACE PR010/T unit will display the following message:
'WARNING.SW updating failed'
'Press ESC to restart'
and the PC will display the message:
'Time out error: cannot contact PR010/T'
11. Press ESC on the SACE PR010/T unit to return to the screen:
'Program failed'
'ENTER for recovery'
12. Select PROGRAM/from CONFIGURATION in the "PR010/T Program" of the PC.

13. Proceed as described in point 7 onwards.

5.2.2 Test report downloading procedure

1. Switch on the SACE PR010/T test unit.
2. Using the cable supplied, connect the unit to one of the PC's serial ports
3. Run the "SD-TU Interface" program.
4. On the PR010/T menu select **Get report**
5. On the main menu of the SACE PR010/T unit, select
'2.Report Download',
the following message will be displayed:
'Test report download'
'ENTER to start'
6. Press ENTER on the SACE PR010/T unit to display the following message:
'Waiting for report download'.
Before one minute elapses, press the **Get report** key in the window "get report from PR010/T" displayed on the PC.
7. The SACE PR010/T unit will now display the message:
'Download in progress'
accompanied by a progressive status bar indicating the download time remaining. The maximum transmission duration is about one minute.
8. If the file is not successfully downloaded, the SACE PR010/T unit will display the message:
9. 'END report download'
10. 'Press ESC to restart'
11. while the PC will automatically open the Report window displaying what has been received.
12. Press ESC on the SACE PR010/T unit to return to the main menu.
13. If the file is not successfully downloaded, the SACE PR010/T unit will display the message:
'Download aborted'
'Press ESC to return'
14. The PC will display the message "Timeout error: cannot contact PR010/T"
15. Press ESC and resume as described in point 4 onwards.
16. In the event of problems not described in this section, refer to the "Error messages and troubleshooting table".

5.2.3 **Test report erasing**

The following procedure entirely erases the test reports stored in the PR010/T:

- 1. Switch on the SACE PR010/T test unit.
- 2. On the main menu of the SACE PR010/T unit, select:
 '2.Report Download'
 '2.Erase'

The following message will be displayed:

'Report erasing'
'ENTER to proceed'
'ESC to return'

Select ENTER to erase the report.

5.3 **Protection unit**

See annex RH0029002.

6. **Technical specifications**

6.1 **User interface**

The user interface comprises an alphanumeric display, membrane keyboard and indicator led.

Each time a key is pressed, an acoustic signal is emitted. The back-lit LCD display features 4 lines each containing up to 20 characters.

The display's back-lighting automatically switches off when the keyboard is idle, unless connected to the external power supply.

If no key is pressed for at least 5 minutes the display switches off automatically to minimise electrical consumption.

6.2 **Power supply**

The SACE PR010/T test unit is a portable instrument operated by 6 rechargeable batteries and/or an external power supply.

When installing the rechargeable batteries in the PR010/T unit, pay attention to the polarity indications in the space provided for the batteries.

The **specifications of the external power supply** supplied are as follows:

Vin	= 100...240 Vac (47...63 Hz)
Vout	= 12 Vdc \pm 5%
Max output current	= 2.7A

The **specifications of the rechargeable batteries** supplied are as follows:

Size	AA
Type	NiMH
Voltage	1.2V
Capacity	1300 mA/h

The operating autonomy of the batteries during testing depends on the type of release tested, the type of tests performed, the different release versions and the operations performed by the user. When testing, for example, a PR112/P unit the batteries operate for about 2 hours under test conditions and 6 hours in stand-by mode.

The battery recharge time is about four hours with unit switched off.

The batteries recharge automatically when the SACE PR010/T test unit is connected to the external power supply.

The rechargeable batteries are supplied discharged. The batteries must therefore be charged before using the PR010/T test unit for the first time.

The test unit may also be connected to the external power supply.

6.3 Inputs/Outputs

The SACE PR010/T test unit uses a set of signals to perform its various testing, programming and reading functions. The main characteristics of these signals are as follows:


Output voltage range:	- 5 ... +12 Vdc
Maximum output current:	1A constant
Input voltage range:	0 ... +15 Vdc
Minimum input impedance:	1 Mohm

6.4 Mechanical specifications

Plastic enclosure		
Front panel protected against electrostatic discharges		
Dimensions:	Length	= 210 mm
	Max. width	= 120 mm
	Max. depth	= 60 mm
Protection class:	IP30	
Weight (complete with rechargeable batteries):	600 g	
Operating temperature range:	0 °C ... +50 °C	
Storage temperature range:	-20 °C ... +70 °C	
Maximum relative humidity:	90%, (non-condensing)	
MTBF:	15 years @ 30°C	

6.5 Standard equipment

The SACE PR010/T test unit is supplied in a special case, complete with the following accessories:



1. SACE PR010/T test unit complete with rechargeable batteries
2. SACE TT1 TRIP TEST unit
3. External power supply
4. 1m length cables with connectors suited for several types of electronic releases.
5. External power supply connection cable
6. PC connection cable
7. User manual and application software
8. Set of adapters for different types of releases
9. Batteries

6.6 Applicable standards

The SACE PR010/T test unit bears the CE quality mark and fully complies with all major international standards on electromagnetic compatibility (EMC).

Emissions:	IEN55022 class B
Electrostatic discharge:	IEC/EN 61000-4-2
Radiated immunity:	IEC/EN 61000-4-3
Conducted immunity:	IEC/EN 61000-4-6 (1kV)

6.7 Error messages and troubleshooting table

UPDATE ERROR	
"SW updating failed" "Press ESC to restart"	This message indicates a software updating error. To rectify, repeat the operation, after first checking the PC-PR010/T connection and the name of the loaded file.
COMMUNICATION ERROR	
"Communication error" "Press ESC to return"	This message indicates that the SACE PR010/T's internal bus is unable to establish a connection with the device under test.
INVALID DIGITAL VOLTAGE	
"DUT internal voltage not valid" "Press ESC to return"	This message indicates an internal DUT voltage reading that is outside the accepted range.
INVALID PROGRAM	
"Program failed" "Press ENTER for recovery"	If this message is displayed when the SACE PR010/T test unit is powered up, it means that the program stored in the SACE PR010/T's memory is incorrect due to the failure of a previous software updating sequence. In this situation, the SACE PR010/T test unit cannot work and must therefore be reloaded with the updated software.

INVALID WATCH DOG

"Control signal not valid"

"Press ESC to return"

This message indicates that the internal control signal is outside the established range. Check the connection between the SACE PR010/T test unit and device under test.

The following error messages are displayed on the SACE PR010/T unit:

Troubleshooting guide			
No.	Faults	Causes and errors	Checks and remedies
1	The POWER-ON led is not lit	The external power supply is disconnected	Power up the unit with the power supply provided by ABB SACE
		The external power supply is not connected to the mains power supply	Connect the power supply to a 220V power mains
		No batteries fitted	Fit batteries like the ones specified under the heading "Power supply"
		The batteries are flat	Recharge the batteries by connecting the unit to the external power supply
2	The message display is not clear	The contrast and/or brightness setting(s) are incorrectly adjusted	Adjust as described under the heading "Test unit configuration"
3	The display language is incorrect	The language setting is incorrectly programmed	Switch on the unit and 10" later select: 3. ENTER ENTER ENTER Select the correct language with UP and DOWN.

Troubleshooting guide

4 Problems updating the software installed on the PR010/T unit	Wrong connection cable used to connect the PC to the PR010/T test unit	Replace with the cable supplied and repeat the operation
	The serial cable is not properly connected	Make sure the cable connectors are properly inserted
	The PR010/T unit is not ready for Sw updating	Proceed as described under the heading "Sw updating procedures"
	The PR010/T's time-out elapses before the software starts update	Make sure the PR010/T unit displays the message "Waiting for update" at the start of the file downloading from the PC transfer procedure
	The update file is not selected	Select the required software version and repeat the update procedure
	The wrong type of file is selected	Select file type PR010t_x.Hex
5 Problems downloading the test report to the PC	The file downloaded is damaged	Use a spare copy or download the updated software version from our Internet site
	Wrong connection cable used to connect the PC to the PR010/T test unit	Replace with the cable supplied and repeat the operation
6 Problems connecting the cable to the device under test	The serial cable is not properly connected	Make sure the cable connectors are properly inserted
	The PR111-type release is fitted with the wrong adapter	Fit the correct PR111 adapter
	The PR111 adapter is damaged	Replace with the spare one supplied
	A cable for the Isomax series is connected to an Emax circuit breaker, or vice versa	Use the correct cable for the circuit breaker

6.8 Notes

In view of ongoing revisions to Standards and the latest developments in technology and materials, the characteristics (mechanical, electrical and electronic) and overall dimensions indicated in this handbook are only deemed legally binding subject to confirmation by ABB SACE.

The test unit does not need recalibrating.



WARNING

If necessary, the device may be operated by standard AA-type batteries (non-rechargeable), provided the unit is not simultaneously connected to the external power supply.

ATTENTION

COMPATIBILITY BETWEEN WINDOWS OPERATING SYSTEMS AND SD-TEST UNIT INTERFACE

Operating System	Installation requirements	Operating requirements	Notes
Windows XP or earlier	Any user	Any user	
Windows 7	Administrator user	Any user ⁽¹⁾	(1) Use with “non administrator” profile can be obtained by installing the latest SD-Test Bus Interface version available (from file 1SDC200002X0005 15.zip or more recent)
Windows 10	Administrator user	Administrator user	

ERROR MESSAGES, TROUBLESHOOTING

Updating of faults described in chap. 6.7 of Instruction RH0025002:



























N°	Faults	Causes and errors	Checks and remedies
7	Difficulties in updating PR010/T: <ul style="list-style-type: none"> - Display locked on “updating”. - Display locked on start-up screen. 	During an update could be caused by: <ul style="list-style-type: none"> - Power outage. - Cable between PR010/T and PC has detached. - Driver of serial line to PC is locked. 	<ol style="list-style-type: none"> 1. Shut down PR010/T and remove power supplier if connected. 2. Restart PR010/T. 3. Press STOP button within 2s from powering: this will prepare unit for re-programming. 4. Comply with instructions on display.

ABB SACE		SACE PR010/T	RH0025002 UPDATING 2017	L7680	1/1
-------------	---	-----------------	----------------------------	-------	-----

ABB SD-Test Unit Interface

File PR010/T Help

Device Selection

-   ABB SACE Devices
-  PR111 (IEC version)
 -  PR111 (UL version)
 -  PR111/VF
 -  PR112 (IEC (A-D))
 -  PR112 (IEC (M-Z))
 -  PR112 (UL version)
 -  PR113 (IEC version)
 -  PR113 (UL version)
 -  PR212
 -  PR212MP
 -  PR222
 -  PR222MP
 -  PR223EF
 -  PR223DS
 -  PR121
 -  PR122
 -  PR123
 -  PR232
 -  PR232/T8
 -  PR331
 -  PR332
 -  PR333
 -  PR122/DC
 -  PR123/DC

Device

SACE PR010/T Test Unit Annex



ABB SACE



SACE PR010/T

RH0029002

L4408

EN

INDEX

1. Information about the functions of the SACE PR010/T unit (release 7.7)	3
1.1 Type of connection cables	4
1.1.1 CABLE A	4
1.1.2 CABLE B	4
1.1.3 CABLE C	4
1.1.4 CABLE D	5
1.1.5 CABLE E	5
1.2 Menu tree	5
2. SACE PR11x/PR212x/PR222x/PR223x protection relays	6
2.1 Operating mode menu	6
2.2 Test	6
2.2.1 Trip test	7
2.2.2 Manual test	7
2.2.3 Automatic test	8
2.2.4 Set/Reset Coil test	8
2.2.5 Inst test	8
2.2.6 Notes about the Relays	9
2.3 Reading	11
2.3.1 Measuring	11
2.3.2 Parameters/Configuration	11
2.3.3 Protections	12
2.3.4 Trip history	12
2.3.5 General information	12
2.4 Programming	12
2.4.1 Configurations	13
2.4.2 Protections	13

3. SACE PR12x/PR232/PR33x/PR12xDC protection relays	14
3.1 Mechanical connection	14
3.2 Operating mode menu	15
3.3 Test	15
3.3.1 Automatic Test	16
3.3.2 Manual Test	16
3.3.3 Trip test	17
3.3.4 Module Test	17
3.3.5 S and G selectivity	17
3.3.6 RC Test	17
3.4 Measuring	18
3.5 Histories	19
3.5.1 Trips	19
3.5.2 Events	19
3.5.3 Statistics	19
3.6 Configurations	20
3.6.1 Circuit-breaker	21
3.6.2 Alive LED	21
3.6.3 Modules	22
3.6.4 Local Bus unit	22
3.6.5 System	23
3.7 Parameters	23
3.7.1 Limitations	24
3.8 Information	25
3.8.1 Download	25
3.9 Status	26
3.10 Installation	26
3.10.1 Disinstallation	26
3.10.2 Installation	26
3.11 Automatic Test: full description	27
3.11.1 PR121/P, PR331/P; PR122/P and PR332/P without measuring module	27
3.11.2 PR122/P and PR332/P (with measuring module)	27
3.11.3 PR123/P and PR333/P	28
3.11.4 PR232/P and PR232/P-T8	28
3.11.5 PR122/DC	29
3.11.6 PR123/DC	29

1. Information about the functions of the SACE PR010/T unit (release 7.7)

The SACE PR010/T unit can be connected to different types of ABB SACE electronic relays (also known as DUT) in order to perform tests, program and read parameters.

Using a cable and adapters, the PR010/T unit can be connected to the test connector of the relay, installed at the front. A list of relays compatible with the PR010/T unit is given below, along with the type of cables required for the connection.

RELAY (1)	CIRCUIT-BREAKER	TYPE OF CABLE	ADAPTER
PR111	EMAX	A	X
PR111/VF	EMAX VF	A	X
PR112 (2) (4)	EMAX	A / B	X
PR113 (4)	EMAX	B	
PR212 (3)	ISOMAX	C	
PR212MP (3)	ISOMAX	C	
PR222 (4) (5)	TMAX T4-T5-T6	D	
PR222MP	TMAX T4-T5-T6	D	
PR223DS (5)	TMAX T4-T5-T6	D	
PR223EF (5)	TMAX T4-T5-T6	D	
PR232	TMAX T7	E	X
PR232-T8	TMAX T8	E	X
PR331	TMAX T7-T8 / EMAX X1	E	X
PR332	TMAX T7-T8 / EMAX X1	E	X
PR333	EMAX X1	E	X
PR121	NEW EMAX	E	
PR122	NEW EMAX	E	
PR123	NEW EMAX	E	
PR122DC	EMAX DC	E	
PR123DC	EMAX DC	E	

NOTES

- 1 In all IEC and UL releases available, unless there is an additional note
- 2 Consult the details in the next chapter for connection to PR112
- 3 Connection only available for versions with a front test connector
- 4 Auxiliary voltage must be available for the PD relay versions
- 5 When the PR010T unit is connected, a relay normally connected to an external system temporarily interrupts the communication with this latter


1.1 Type of connection cables

The diagrams below illustrate examples of the types of cables available for connecting the various different relays to the PR010/T unit.

All cables are supplied as accessories of the PR010/T unit.


1.1.1 CABLE A

The diagram shows an example of connection to a PR111 relay with the aid of a mechanical adapter. Cable to be used for the IEC version of the PR112 relay with key.




1.1.2 CABLE B

The diagram shows an example of connection to an IEC version of a PR112 relay without key. Cable to be used for the IEC version of the PR112 relay without key and for the UL version of the PR112 relay.




1.1.3 CABLE C

The diagram shows an example of connection to a PR212/MP relay (only for the version with front connector).




1.1.4 CABLE D

The diagram shows an example of connection to a PR223EF relay.



1.1.5 CABLE E

The diagram shows an example of connection to a PR331 relay with the aid of a mechanical adapter.



1.2 Menu tree

When connected to the SACE relay, the PR010/T relay allows all the available functions and information to be accessed by means of a tree menu.

For some of the relays, the structure of the tree menu (and the available functions and information) is very similar: they can thus be grouped into two categories, as shown in the table below:

RELAY	CIRCUIT-BREAKER	CHAPTER
PR111; PR111/VF; PR112; PR113	EMAX	3
PR212; PR212MP	ISOMAX	
PR222; PR222MP; PR223EF; PR223DS	TMAX T4-T5-T6	
PR232; PR232-T8; PR331; PR332; PR333	TMAX T7-T8 / EMAX X1	4
PR121; PR122; PR123	NEW EMAX	
PR122DC; PR123DC	EMAX DC	

2. SACE PR11x/PR212x/PR222x/PR223x protection relays

2.1 Operating mode menu

All the SACE relays belonging to this group partly or fully share certain of the functions and characteristics.

Considering the main menus, all unit can access the following menus:

- *Test*: tests of the protections, trip mechanism and high signals.
- *Reading*: monitoring of the current values, relay and circuit-breaker parameters, trip history and other information in general.
- *Programming*: editing of the relay and circuit-breaker parameters, the protection status and other configuration data.



CAUTION

During access to the menus, an error message could appear for certain of the relays, if the CB type and TA current rating have not yet been defined.

2.2 Test

The tests available with the various different SACE relays are listed in the table below.

	PR111	PR111VF	PR112	PR113	PR212	PR212MP	PR222	PR222MP	PR223EF	PR223DS
TEST (1)										
Trip Test			X	X		X	X	X	X	X
Manual protections	X	X	X	X	X(2)	X(2)	X(2)	X(2)	X	X
Automatic protections	X	X	X	X	X(2)	X(2)	X(2)	X(2)	X	X
Set/reset Coil						X		X		
Inst protection	X		X	X						

NOTES

- 1 Perform the trip test with the circuit-breaker Closed and the protection test with the circuit-breaker Open.
- 2 The automatic test and manual test with the default parameters can only be performed by using the Electronic SET configuration for the relay (ELT) by means of the relative dip switch.

2.2.1 Trip test

The trip test must be performed with the circuit-breaker closed. This test allows a circuit-breaker trip command to be transmitted so as to check the operation of the relay opening system if tripping is caused by an overload or short-circuit.

2.2.2 Manual test

The manual test must be performed with the circuit-breaker open.

Two different configurations are available: test with default parameters and with user parameters:

- *Test with user parameters:* this can be performed by setting the unit in the ELT or MAN configuration. The protection parameters are at the user's discretion in this mode.
- *Test with default parameters:* this can only be performed by setting the unit in the ELT configuration. The protection parameters are preset in this mode.

In the manual test, the tripping time of the electronic relay can be tested with the desired load condition and allows the user to select the reference protection (e.g.: L, S...), the threshold and time of the protection (e.g.: I1, t1, I2, t2...), the fault current (If or I-f) and the phase (e.g.: L3, Ne...).

The \uparrow and \downarrow keys can be used to scroll the various different options available (type of protection, time settings, thresholds and curves). Press ENTER to confirm the selection.

Use keys \leftarrow and \rightarrow to increase/decrease the protection parameter settings and select the phase..

The tripping time of the relay will depend on the protection settings. The PR010/T unit displays the tripping time and test result (OK, FAILED).

NOTE: Reading of the protection settings is automatic for some relays while entry in the manual mode by the user is required for others.

At the end of the test, the user is asked whether a test report must be recorded. This can then be downloaded into a PC using the dedicated SD User Interface tool.



CAUTION

When the test parameters are defined, make sure that the value of the tripping current is higher than the threshold of the tested protection.



CAUTION

Make sure that the selected test current does not trip other protections besides the one being tested: these trips will be signalled as FAILED by the unit. This can be avoided by changing the threshold values of the protections and the test current.



CAUTION

The test with the default configuration is available up to version 7.5 (inclusive)

ABB SACE	ABB	SACE PR010/T	RH0029002	L4408	7/29
----------	------------	--------------	-----------	-------	------

2.2.3 Automatic test

The automatic test must be performed with the circuit-breaker open.

The data acquisition channels are tested for each phase (L1, L2, L3, Ne) and the main protections of the unit are tested (e.g. trips with protections: L, S, I and G with PR212/P LSIG; L, R, I, U with PR222MP) for each relay, regardless of its functional characteristics and version..

During the various different tests, the tripping times of the relay will depend on the protection settings. The PR010/T unit displays the threshold and time of the protection in question, as well as the test result (OK or FAILED).

At the end of the test, the user is asked whether a test report must be recorded. This can then be downloaded into a PC.

2.2.4 Set/Reset Coil test

Operation of the SET and RESET outputs that control the PR212/CI unit can be tested for the MP relay versions (PR212MP and PR222MP). Each test command transmits a status change signal to the PR212/CI unit.



CAUTION

Before transmitting a Set/Reset test command, make sure that the PR212/CI unit is in the opposite position, so as to check the switching function.

2.2.5 linst test

Operation of the linst protections can be tested in PR11x series relays. The PR010/T unit will display the test result (OK or FAILED).



CAUTION

Before accessing the menu, make sure that the circuit-breaker model and the setting of the dip switch on the upper side of the relay correspond. If they are misaligned, an error message will be displayed by relays PR112 and PR113, and access to the menu will be inhibited.

2.2.6 Notes about the Relays

Consider the following indications to ensure that the tests are performed correctly.

2.2.6.1 PR111 and PR111/VF

- Before any test can be performed, certain data concerning the model and size of the CB must be entered (e.g.: E1B, 800A). The Neutral setting (50% / 100%) and the version of the unit (LI, LSI, LSIG) must also be entered in certain cases.
- Enter the settings of the protections in the following way before performing the Automatic test:

Protection	Threshold	Time
L	$I1 = 0.4I_n$	$t1 = B$
S	$I2 = 3I_n$	$t2 = C; I^2t = k$
I	$I3 = 8I_n$	--
G	$I4 = 0.8I_n$ (IEC version) $I4 = 0.4I_n$ (UL version)	$t4 = B$

NOTE: the PR111/VF relay does not control protections S, G and Inst. This means that the setting of the G protection must not be considered for automatic test configuration.

- The maximum trip time tolerance is 35% for the G function.
- The minimum threshold in the Manual Test configuration is $0.6I_n$ for the G function.

2.2.6.2 PR112

- PR10/T unit compatible with all PR112 relays in the IEC version with key, 2.20 SW version or more recent and serial number after xxxxxx03x (for PR112/P units) or xxxxx05x (for the PR112/PD versions).
- Notes for the G protection function test:
 - For the automatic test, the $I4$ threshold setting must be $0.4I_n$ or more (if a lower value was entered, the PR10/T unit would automatically override to $0.4I_n$ during the test). The value of the test current is $2.5 \times I4$.
 - The value of the test current in the manual test is $1.5I_n$.
 - After a test with tripping on the G protection function, the protection may trip several times more during the next 2s.
- PR112 contact wear: during the PR112 test, the operation count and contact wear signal could increase after the opening command has been generated with over 10s timing. After a few tests, the wear could reach 100% of the value and lead to an EMERGENCY warning. This warning can be reset by the customer in the following way:
 - Access the READ mode and select the page containing the contact wear indication
 - Turn the key to EDIT
 - Press the "Up" and "Down" keys for at least 5s. This will reset the contact wear and operation count indication.

2.2.6.3 PR113

- The tests must be performed with the circuit-breaker open, no busbar voltage ($V=0$) (in the point where the TV for measuring the voltage of relays PR113/P and PR113/PD are installed) and with auxiliary power supplied.

2.2.6.4 PR212 and PR222

- The manual test can be performed with both the electronic SET (ELT) and manual SET (MAN). In the manual test with manual SET, the thresholds and curves are selected with the dip switches on the protection and are automatically updated on the display of the PR010/T unit, where only the phase and test current must be set.

2.2.6.5 PR212MP and PR212MP

- In the test with PR212/MP relay version 1 (data item read automatically by the PR010/T unit), the maximum test current is $7.3I_n$. For this reason, the automatic test will test the protection functions in accordance with the indications given above and using this value as the limit.
- The manual test can be performed with both the electronic SET (ELT) and manual SET (MAN). In the manual test with manual SET, the thresholds and curves are selected with the dip switches on the protection and are automatically updated on the display of the PR010/T unit, where only the phase and test current must be set.
- If there is no PTC for protection against overtemperatures, the "Input" dip-switch must be set as a generic input (Input = 0/1) during the test.
- The "Welded contacts" input (WC) setting must be 0 V (no alarm) during the test.
- At the end of each test, the PR010/T unit will wait until the thermal memory has reset before proceeding with any further tests so as to prevent tripping overlaps between the tested function and the overload function (L).
- Before testing the rotor blocked protection function (R), the PR010/T waits an initial time linked to the class setting of protection function L (lasting 24s at most).

2.2.6.6 PR223EF

- If the default settings are used, the front Interlocking LEDs will come on when the relays are powered with the PR010/T unit. The protection and configuration settings can be changed to suit the installation requirements.
- The EF protection must be de-activated beforehand in SW versions prior to 4.00, otherwise the test result will be negative.

2.3 Reading

The data available in the Reading mode with the various different SACE relays is given in the table below.

	PR111	PR111/VF	PR112	PR113	PR212	PR212MP	PR222	PR222MP	PR223EF	PR223DS
READING										
Current measuring			X	X	X	X	X	X	X	X
Other measurements				X ₍₁₎		X ₍₂₎	X	X ₍₂₎	X ₍₃₎	X ₍₁₎
Parameters/ Configuration ⁽⁴⁾			X	X	X	X	X	X	X	X
Protections			X	X			X		X	X
Trip history				X	X	X	X ₍₄₎	X	X	X
General information			X	X	X	X	X	X	X	X

NOTES

- 1 Voltage, Power, Energy Counter, Power Factor, Frequency and peak factor measurements available
- 2 Readings of generic input 0/1 available
- 3 Voltage, Frequency and peak factor measurements available if accessory module VM210 is installed
- 4 Trip history reading available for relay versions /PD

2.3.1 Measuring

The measurements are displayed in absolute values (e.g.: Amperes for the current values, Volts for the voltage values). The reading of a nil or unavailable value (because it is too low) is indicated by: "..." or an empty space.

2.3.2 Parameters/Configuration

This section displays the relay's configuration parameters and information, including the size of the CB, the neutral setting, the version of the relay, the language, frequency setting, the rated voltage, the external contacts, etc.

The availability of information depends on the maximum performance of the relay, as indicated in the relative table. Scroll the menu to display the data of the DEFAULT version (this function is available with up to 7.5 SW versions of the PR010/T unit 7.5).

Use the  and  keys of ENTER to scroll the sections.

2.3.3 Protections

The parameters of the main relay protections are displayed in this section.

Use the \uparrow and \downarrow keys of ENTER to scroll the sections.

2.3.4 Trip history

This section contains the data stored during the last tripping action of the relay, such as the current readings, tripping protection and the total number of trips.

The PR223EF and PR223DS relays can store up to 20 historic data items. Use the \uparrow and \downarrow keys or ENTER to scroll the records.

2.3.5 General information

This section contains data such as the name of the relay, the SW release and the serial number.

2.4 Programming

The data that can be configured with the ACE relays are given in the table below.

	PR111	PR111/MF	PR112	PR113	PR212	PR212MP	PR222	PR222MP	PR223EF	PR223DS
PROGRAMMING										
Parameters/ Configuration ⁽¹⁾			X	X	X	X	X	X	X	X
Protections			X	X	X ₍₂₎	X ₍₂₎	X ₍₂₎	X ₍₂₎	X	X
NOTES										
1 For PR010/T unit SW releases up to 7.5, the settings can also be programmed in the DEFAULT configuration in the operating mode and the test parameters in the DEFAULT configuration)										
2 The protection parameters can be programmed in the ELT configuration										

2.4.1 Configurations

In this section, the user can enter the settings of many different parameters concerning the relay and circuit-breaker, such as the size of the CB, the frequency, the Neutral setting, the programmable contacts, the communication parameters, etc.

Use the \uparrow and \downarrow keys within the menu to position the cursor on the required parameter, then change the values of the parameters within the permitted range using the \leftarrow and \rightarrow keys. Once the changes have been made, press ESC to display the confirmation page.

2.4.1.1 PR223DS: Current Measure Calibration

The current readings in the PR223DS relay can be corrected in the manual mode by means of the calibration procedure.

The relay only accepts corrections for current values exceeding 0.05In. The maximum deviation in relation to the value read without calibration is 5%. Calibration can be reset by restoring the default configuration (the “Restore Default” command in the calibration menu).

2.4.1.2 PR223EF: S51/P1 Contact configuration

The option allowing the status of contact S51/P1 and the external contacts to be configured and read is available from relay release 3.01 onwards.

2.4.2 Protections

The settings are made by means of the same procedure used for programming the configuration parameters.

Different protections are available, depending on the model and version of the relay. Consult the manuals and catalogues of the individual values for a full description.

With PR223EF, the type of interlock for the IL protection (Driver), required for connection to relays of a different type, is available from release 3.01 onwards. Consult the manual of the unit for details.

3. SACE PR12x/PR232/PR33x/ PR12xDC protection relays

3.1 Mechanical connection


The relays of the following series:

- New Emax (PR121/P, PR122/P, PR123/P)
- Tmax T7-8/Emax X1 (PR232/P, PR232/P-T8, PR331/P, PR332/P, PR333/P)
- Emax DC (PR122DC, PR123DC)

are connected to PR010/T units with the same type of cable.

Use the supplied mechanical adapter to ensure a correct connection with relays of the Tmax T7-8/Emax X1 series. The writing on the adapter of the connected device must point towards the device itself (the example shows how the adapter is assembled for a connection to PR332/P).

Auxiliary power is not required for use of the above mentioned relays with PR010/T units.



3.2 Operating mode menu

All the relays in the previous chapter share the same menu structure in PR010/T units. They also partly or fully share certain functions and characteristics.

Considering the main menus, all the units allow access to the following menus:

- *Test*: test of the protections, trip mechanism and high signals.
- *Measuring*: monitoring of the currents and other runtime values of the relay.
- *History*: historic reading of trips and other stored measurements.
- *Setting configuration*: modifies the characteristic parameters of the relay.
- *Protection configuration*: modifies the protection thresholds and parameters.
- *Information*: reading of the characteristic information of the CB unit and relay.
- *Status*: presence of alarms (if any).
- *Installation*: installation and disinstallation of a new relay in the CB.

3.3 Test

	PR121/P	PR122/P	PR123/P	PR331/P	PR332/P	PR333/P	PR232/P ⁽¹⁾	PR122DC	PR123DC
TEST									
Automatic	X	X	X	X	X	X	X	X	X
Manual	X	X	X	X	X	X	X	X	X
Trip Test	X	X	X	X	X	X	X	X	X
Module sign. ⁽²⁾		X	X	X	X	X		X	X
S and G selectivity ⁽³⁾		X	X		X	X		X	X
Rc ⁽⁴⁾		X	X		X	X			

NOTES

- 1 Relays PR232/P and PR232/P-T8 share the same settings and types of controls in PR010/T
- 2 The note refers to modules PR120/K (for relays PR122 and PR123), and contact S51/P1 (for relay PR33x)
- 3 Test only possible for relay versions with protections S and/or G
- 4 Test only possible if the Rc sensor is connected



CAUTION

The Test menu cannot be accessed if there is an alarm or if the circulating current is not nil.

3.3.1 Automatic Test

The automatic test must be performed with the circuit-breaker open. With certain relays, it may be impossible to access/run the test if the circuit-breaker is closed.

Various tests are available for each relay, regardless of the functional characteristics.

	PR121/P	PR122/P ^(a)	PR123/P	PR331/P	PR332/P ^(a)	PR333/P	PR232/P	PR122DC	PR123DC
AUTOMATIC TEST									
Three-phase currents	x	x	x	x	x	x	x		
Single-phase currents ⁽¹⁾	x	x	x	x	x	x			
Three-phase voltages		x	x		x	x			
Variable Phase Shift		x	x		x	x			
DC currents								x	x
DC voltage								x	x

NOTES

- 1 L1 is the phase subjected to single-phase testing
- 2 The Voltage and Phase Shift tests are only available for these relays when supplementary modules PR120/V or PR330/V are installed

The trip time settings of the relays during the tests will depend on the settings of the protections. The PR010/T unit will display the trip time and test result (OK; FAILED).

At the end of the test, the user is asked if he wishes to record a test report, which can then be downloaded into a PC.

Details of all the tests performed are given in the chapters dedicated to each individual relay, available from chapter 4.11 onwards.

3.3.2 Manual Test

The manual test must be performed with the circuit-breaker open. With certain relays, it may be impossible to access/run the test if the circuit-breaker is closed.

The manual test allows you to check the trip time of the relay with the required load condition. In detail, you can select the current value within the 0.00 to 16.00 In range, the voltage value within the 0.0 and 1.3 Vn range, the phase shift between -180° and +180° with 0.75° steps (if the relay allows voltages and phase shifts to be tested) and select one or more of the phases involved in the test (L1, L2, L3, Ne, Gte, V1, V2, V3). The phases chosen for the test are indicated by the “→” symbol.

The trip time settings of the relays during the tests will depend on the settings of the protections. The PR010/T unit will display the trip time and test result (OK; FAILED).

At the end of the test, the user is asked if he wishes to record a test report, which can then be downloaded into a PC.

3.3.3 Trip test

The trip test must be performed with the circuit-breaker closed.

This test allows a circuit-breaker opening command to be transmitted, thus checking the functionality of the opening system of the relay itself if tripping is caused by an overload or short-circuit.

3.3.4 Module Test

+24Vdc Auxiliary Power must be available for the Module Test.

During the contact module test (module PR120/K for PR12x series relays and contact S51/P1 for PR33x series relays), all the available contacts are momentarily excited (4 or 5 on module PR120/K and 1 for S51/P1). The user is responsible for checking the physical conditions.

Confirmation that the command has been transmitted is displayed by the PR010/T unit.

3.3.5 S and G selectivity

The zone selectivity tests can only be performed if an auxiliary power supply is available and with the circuit-breaker open.

The commands available in the unit excite the relay's zone selectivity outputs for the respective protections (S and G), thus allowing the wiring to be checked in the installations in which they are wired.

There is a dedicated command in the menu to release the stimulus on the outputs.

3.3.6 RC Test

This test allows a simulated signal to be transmitted to the RC sensor, the current of which, when read by the relay, causes the circuit-breaker to open, thus checking the residual current reading functionality.

3.4 Measuring

Various instantaneous measurements are available for each relay, regardless of the functional characteristics and versions.

Commands for resetting the energy meters and for the measuring history are also available for certain relays.

	PR121/P	PR112/P ⁽¹⁾	PR123/P	PR331/P	PR332/P ⁽¹⁾	PR333/P	PR232/P	PR122DC	PR123DC
MEASURING									
Currents	X	X	X	X	X	X	X	X	X
Peak factors	X	X	X	X	X	X			
Frequency		X	X		X	X			
Voltages, Power ratings, Energy values, Power Factors		X	X		X	X			X
Reset Energy command		X	X		X	X			X
Reset Measuring command		X	X		X	X			X

NOTES

- 1** Measures only available for these relays when supplementary modules PR120/V or PR330/V are installed

The reading of a nil or unavailable current (because it is too low) is indicated by: "...". When there are phase errors, the current is indicated by: "----".

Power measurements (Active, Reactive and Apparent) are available for both single channels and the whole (e.g.: P1, P2, P3, Pt). If the Neutral voltage is absent, the only measurement available is the total (e.g.: Pt).

Ig current is only available with the LSIG version of the relays. For the other versions, if indicated, it is represented by: "----".

3.5 Histories

Certain signals can be displayed for each relay, such as the history of the openings caused by the tripped protection, of the events, as well as certain statistical information about the relay openings.

	PR121/P ⁽¹⁾	PR122/P	PR123/P	PR331/P ⁽¹⁾	PR332/P	PR333/P	PR232/P	PR122DC	PR123DC
HISTORIES									
Trips ⁽²⁾	X	X	X	X	X	X	X	X	X
Events ⁽³⁾	X	X	X	X	X	X		X	X
Statistics ⁽⁴⁾	X	X	X	X	X	X		X	X

NOTES

- 1** Do not store the number of total operations
- 2** Only the real trips are stored: the ones simulated during the test are not considered
- 3** Signals recorded only with Vaux or front battery units installed (with the exception of Contact Wear, which is also controlled with self-powered relays)

3.5.1 Trips

The information recorded for each Trip is displayed on two screen pages. All the trips can be consulted by scrolling the screen pages with the ↑ and ↓ keys.

Each trip has a progressive number and contains information about the protection that caused it, the date and time of the trip (with reference to the relay's internal clock), the contact wear status (CW) and the trip currents recorded.

3.5.2 Events

Each Event recorded includes a description, and the date and time at which it was recorded.

Events are displayed on two screen pages. The complete list of events can be consulted by scrolling the screen pages with the ↑ and ↓ keys.

3.5.3 Statistics

The statistics refer to: Contact Wear, Protection trip operations, Total operations, Manual operations, Failed trips, Trip Test trips.

Relays PR121/P and PR331/P do not store the number of Total Operations.

3.6 Configurations

The configurations and parameters of the relays can be displayed and modified.

	PR121/P	PR122/P	PR123/P	PR331/P	PR332/P	PR333/P	PR232/P	PR122DC	PR123DC
CONFIGURATIONS									
Circuit-breaker	X	X	X	X	X	X	X	X	X
HW trip	X	X	X	X	X	X	X	X	X
Alive LED	X			X					
Frequency	X	X	X	X	X	X			
Measurement storage period		X	X		X	X		X	X
Local Bus threshold		X	X		X	X		X	X
Startup current threshold		X	X		X	X		X	X
Dual Set			X			X			X
Harmonic distortion		X	X		X	X		X	X
Datalogger		X	X		X	X		X	X
Modules		X	X		X	X		X	X
Local Bus unit	X	X	X	X	X	X		X	X
System		X	X		X	X		X	X

The parameters can be changed by means of a procedure using the keypad:

- First choose the parameter/s that need to be changed. A page with a list of the current settings will appear on the display.
- A cursor will automatically set to the first parameter but the \uparrow and \downarrow keys can be used to move it within the page/s and to select other parameters.
- Having selected the parameter on the screen page, press ENTER to access the editing mode (the cursor will flash). Now use the \leftarrow and \rightarrow keys to change the value of the parameters within the permitted range.
- The editing work ends by confirming the changes with ENTER and pressing ESC until a saving window appears (where the operation must be confirmed). The new parameters/data will become operative in the relay after they have been saved.
- The keypad must be used for parameters that require alphanumerical characters (e.g.: CB TAG NAME).

- Press the corresponding key to enter numbers whereas, to enter a letter, first press the CAPS key (▲) and then the corresponding key as many times as the position of the letter on the key itself, like a mobile phone.



CAUTION

With PR121/P, PR331/P and PR232/P relays, certain parameters can only be changed with the dip switches on the front.

3.6.1 Circuit-breaker

Different parameters can be accessed in the Circuit-breaker menu.

	PR121/P	PR122/P	PR123/P	PR331/P	PR332/P	PR333/P	PR232/P	PR122DC	PR123DC
CIRCUIT-BREAKER									
Neutral	X	X	X	X	X	X	X		
Plant Configuration	X	X	X	X	X	X			
CB TAG NAME	X	X	X	X	X	X	X	X	X
User Data	X	X	X	X	X	X	X	X	X
Toroid ⁽¹⁾		X	X		X	X			

NOTES

- 1 The toroid can only be configured if it is present and connected to the unit

3.6.2 Alive LED

The relay status is signalled by the front LEDs in PR121/P and PR331/P units. The “Alive LED”^c, or the signal that the relay is operating in conditions free from alarms or faults, can be enabled/disabled with PR010/T. The Alive LED signal corresponds to a flash from the pre-alarm led every 3 seconds.

The Default relay setting with Alive LED= ON.

Alive LED configuration is available for units with 2.05 or more recent SW releases.

3.6.3 Modules

Each Module has different denominations for each individual family. Consult the User Manual of the relay for further explanations and details.

	PR121/P	PR122/P	PR123/P	PR331/P	PR332/P	PR333/P	PR232/P	PR122DC	PR123DC
MODULES									
Measuring ⁽¹⁾		X	X		X	X			X
Communication ⁽¹⁾		X	X		X	X		X	X
Signalling ^{(1) (2)}		X	X		X	X		X	X

NOTES

- 1 The menus of the individual modules can only be accessed if they are physically present and connected to the relay
- 2 The module is understood as being the sole S51/P1 contact for relays of the PR33x series

3.6.3.1 Signalling Module

The Signalling module provides one or more programmable contacts (Relays).

The activation event/signal is displayed in the menu of each contact. Press ENTER to access the editing mode (the cursor starts flashing). Use the ← and → keys to change the setting of the activation signal.

Press ENTER to display the current setting for “Custom” selections. Events with an arrow (→) alongside indicate which elements are selected.

Use the ↑ and ↓ keys to display the previous/next screen page and activate/deactivate the selected elements with the ← and → keys (the arrow alongside the element is either displayed or removed).

There are 18 blocks, each of which is formed by eight elements displayed in three consecutive screen pages. Up to 8 elements can be activated per block.

The AND/OR logic applied to the selected elements and the minimum relay activation time can be defined in the last screen page of each block.

3.6.4 Local Bus unit

The Local Bus unit is similar to the Signalling module (it provides several open/close contacts: 7 at most) but also allows the presence of the actual unit to be selected/deselected:

Select “Present” to select the presence/absence of a unit on the local bus: if no unit is physically connected, the relay will signal the correlated alarm. The Local Bus unit is available for all the relays, with the exception of PR232/P.

3.6.5 System

Additional data, such as the date/time and language setting can be entered for certain relays. This option is available for all the relays except PR121/P, PR331/P e PR232/P.

3.7 Parameters

The parameters of the relay protections can be displayed and changed.

The availability of some of the protections depends on the relay version:

1. protections S, G and Gext are not available for the LI versions;
2. protections G and Gext are not available for the LSI versions.

	PR121/P	PR122/P (1)	PR123/P	PR331/P	PR332/P (1)	PR333/P	PR232/P	PR122DC	PR123DC
PARAMETERS									
L	X	X	X	X	X	X	X	X	X
I	X	X	X	X	X	X	X	X	X
S	X	X	X	X	X	X	X	X	X
S2			X			X			X
D			X			X			
G	X	X	X	X	X	X			X
Gext (2)		X	X		X	X			
U		X	X		X	X			X
T		X	X		X	X		X	X
LC1		X	X		X	X		X	X
LC2		X	X		X	X		X	X
Iw		X	X		X	X		X	X
Rc (2)		X	X		X	X			
MCR		X	X			X		X	X
UV (3)		X	X		X	X			X
OV		X	X		X	X			X
RV		X	X		X	X			
RP		X	X		X	X			X
UF		X	X		X	X			
OF		X	X		X	X			

NOTES

- 1 UV, OV, RV, RP, UF, OF protections only available when the Measuring module is installed and with versions LSI and LSIG
- 2 Only available for LSIG versions and when the correlated sensor is installed
- 3 Only available when the residual current sensor (Rc) is not installed

The editing/saving modes for the protection parameters is the same as the one described previously for the other configuration parameters.



CAUTION

The protection settings cannot be changed if the relay is in the overcurrent Alarm or Pre-Alarm status.

3.7.1 Limitations

There are limitations to the display/editing modes of some of the protections for relays of the PR12x series, regardless of the SW release.

- The following limitations must be considered for PR121/P relays with software releases prior to 1.10:

1. Startup time protection S:	$0.1s \leq \text{Time} \leq 1.5s$ step 0.01s
2. Startup time protection G:	$0.1s \leq \text{Time} \leq 1.5s$ step 0.01s
3. Startup current activation threshold	not available
4. Control of unit contacts on local bus	not available

- The following limitations must be considered for PR122/P relays with software releases prior to 1.10:

1. Startup time protection S:	$0.1s \leq \text{Time} \leq 1.5s$ step 0.01s
2. Startup time protection G:	$0.1s \leq \text{Time} \leq 1.5s$ step 0.01s
3. Startup time protection Gext:	$0.1s \leq \text{Time} \leq 1.5s$ step 0.01s
4. Startup current activation threshold	not available
5. Threshold protection U:	$5\% \leq th \leq 90\%$ step 5%
6. Control of unit contacts on local bus	not available

- The following limitations must be considered for PR123/P relays with software releases prior to 1.10:

1. Startup time protection S:	$0.1s \leq \text{Time} \leq 1.5s$ step 0.01s
2. Startup time protection S2:	$0.1s \leq \text{Time} \leq 1.5s$ step 0.01s
3. Startup time protection G:	$0.1s \leq \text{Time} \leq 1.5s$ step 0.01s
4. Startup time protection Gext:	$0.1s \leq \text{Time} \leq 1.5s$ step 0.01s
5. Startup time protection D:	$0.1s \leq \text{Time} \leq 1.5s$ step 0.01s
6. Startup current activation threshold	not available
7. Threshold protection U:	$5\% \leq \text{th} \leq 90\%$ step .5%
8. Minimum custom datalogger enabling time	not available

3.8 Information

This menu displays information about the relay and circuit-breaker.

The menu can also be accessed so as to download information from the PR010/T unit to the PC. The download requires a dedicated procedure. It is not available for PR232/P.

3.8.1 Download

A file is created containing a first group of information, stored in the non-volatile memory of the PR010/T unit. You will be asked to enter certain information for heading the report, namely the date, time, operator's name and CB Serial Number.

This file can be downloaded into a PC in the same way as the normal test reports are downloaded.

The Download info 2 command can also be used to download a group of useful information.

Vacant space must be created in the memory before the data are stored and downloaded into the PC.

Only one group of information can be stored at a time by freeing space (deleting reports) before storing another group. For example, if you wish to download all the information (download info 1 and download info 2):

1. Delete any reports to free sufficient space in the non-volatile memory
2. Perform download 1
3. Download the corresponding file into the PC
4. Delete reports
5. Perform download 2
6. Download the corresponding file into the PC
7. Delete reports to free sufficient space for the report of a next test

3.9 Status

This menu allows you to display configuration/wiring error signals of the protection unit and circuit-breaker concerning:

- The status of the 3 current reading sensors (L1, L2, L3, Ne, Gtext)
- The status of the mechanical release (TC)
- The status of the rated current detector applied to the front (Rating Plug)
- Installation error
- Internal error of the device
- Date error
- Parameters/protections Configuration error
- Circuit-breaker (CB) error

Refer to the user manual of the relay for instructions about how to resolve the errors.

3.10 Installation

This menu describes the installation and disinstallation commands, of use if certain information must be exchanged between the circuit-breaker and relay, when this latter is replaced.

3.10.1 Disinstallation

The disinstallation procedure is not strictly necessary, but it allows the circuit-breaker parameters, such as contact wear and others that would otherwise be lost, to be stored.

The operation is performed on the relay that must be removed and replaced, while it is still assembled on the circuit-breaker and with this latter open.

After disinstallation, the part can be replaced and successively installed.

3.10.2 Installation

The operation is performed on the new unit that must be installed, after it has been assembled and wired and with the circuit-breaker open.

If both operations are performed correctly, the user returns to the main menu and will have to repeat the relay log-in.



CAUTION

For both operations, when the following screen page appears: “Switch off relay” means: “remove any Vaux present”.

```
Install/Disinstall
done
Switch off relay
and press ENTER
```

3.11 Automatic Test: full description

Details of the automatic tests performed on the individual electronic relays are described below.

The result and length of the protection tests depends on the thresholds and values entered by the user.

3.11.1 PR121/P, PR331/P; PR122/P and PR332/P without measuring module

Test N°	Phase			Value
	L1	L2	L3	
1	■	■	■	0.3 In
2	■	■	■	3.0 In
3	■	■	■	5.0 In
4	■	■	■	10.0 In
5	■	■	■	15.0 In
6	■			0.3 In
7	■			3.0 In

3.11.2 PR122/P and PR332/P (with measuring module)

Test N°	Phase						Amplitude		Phase Shift	
	L1	L2	L3	V12	V23	V31	I [In]	V[Un]	Φ	
1	■	■	■	■	■	■	3.0	1.0	30°	
2	■	■	■	■	■	■	5.0			
3	■	■	■	■	■	■	10			
4	■	■	■	■	■	■	15			
5	■			■	■	■	0.3	1.0	0°	
6	■			■	■	■	3.0			
7	■	■	■	■	■	■	0.3	1.0	210°	
8	■	■	■	■	■	■	3.0			
9	■	■	■	■	■	■	5.0			
10	■	■	■	■	■	■	10			
11	■	■	■	■	■	■	15			
12				■	■	■	0.0	0.4	---	
13				■	■	■		1.3		

3.11.3 PR123/P and PR333/P

Test N°	Phase						Amplitude		Phase Shift Φ
	L1	L2	L3	V12	V23	V31	I [In]	V[Un]	
1	■	■	■	■	■	■	3.0	1	30°
2	■	■	■	■	■	■	5.0		
3	■	■	■	■	■	■	10		
4	■	■	■	■	■	■	15		
5	■			■	■	■	0.3	1	0°
6	■			■	■	■	3		
7	■	■	■	■	■	■	0.3	1	210°
8	■	■	■	■	■	■	3		
9	■	■	■	■	■	■	5		
10	■	■	■	■	■	■	10		
11	■	■	■	■	■	■	15		
12				■	■	■	0.0	0.4	
13				■	■	■		1.3	

3.11.4 PR232/P and PR232/P-T8

Test N°	Phase			Value
	L1	L2	L3	
1	■	■	■	0.5 In
2	■	■	■	3.0 In
3	■	■	■	5.0 In
4	■	■	■	8.0 In
5	■	■	■	12.0 In

3.11.5 PR122/DC

Test N°	Amplitude	
	I [In]	V[Un]
1	3.0	1
2	5.0	1
3	10	1

3.11.6 PR123/DC

Test N°	Amplitude	
	I [In]	V[Un]
1	3.0	1
2	5.0	1
3	10	1
4	0.3	1
5	3	1
6	0	0.4
7	0	1.3
8	-0.4	1
9	-3	1
10	-5	1
11	-10	1

ABB SACE	ABB	SACE PR10/T	RH0029002	L4408	29/29
----------	------------	-------------	-----------	-------	-------