

TECHNICAL DATA

Fluke GFL-1500 Solar Ground Fault Locator





END-TO-END FAULT SOLUTION
Identify and locate active ground faults
anywhere in the DC system with an easy-tofollow traceable signal

REDUCED TROUBLESHOOTING TIME

Reduce the amount of time it takes to locate active ground faults and decrease your exposure to electrical hazards with non-contact signal tracing

WORK SAFELY

CAT III 1500 V DC/CAT IV 600 V rated GFL-1500 Transmitter and GFL-1500 Receiver, with a GFL-1500 Clamp rated for use on insulated conductors up to 1500 V.

Revolutionize Fault Location, Maximize Solar Production

The Fluke GFL-1500 Solar Ground Fault Locator is a frontline troubleshooting tool that helps technicians quickly pinpoint active ground faults in solar photovoltaic (PV) systems. It works by producing a traceable signal in the array, allowing for fast, intuitive, non-contact tracing directly to the fault location. This innovative approach eliminates the frustration of time-consuming, brute-force troubleshooting and reduces unnecessary exposure to electrical hazards.

In addition to improving safety and reducing downtime, this innovative solution redefines how technicians locate active ground faults in solar PV systems. By replacing complex, manual diagnostics with an easy-to-follow trace signal, the GFL-1500 streamlines fault isolation, helping teams restore system operation quickly and effectively.

The GFL-1500 Ground Fault Locator is a three-piece troubleshooting system designed to optimize technician workflow in the field, enabling faster and more confident fault resolution. This gives site managers greater assurance in system performance and uptime. The GFL-1500 system consists of the GFL-1500 Transmitter, GFL-1500 Receiver, and GFL-1500 Signal Tracing Clamp.







FaultTrack[™] Technology — Solar Ground Fault Detection

The GFL-1500 utilizes FaultTrack[™] Technology to detect active faults and generate a traceable signal through the fault path, enabling technicians to follow that signal from the transmitter through the faulted path to the precise point of failure. Pinpointing the exact location of an active fault used to be a challenge—with FaultTrack[™] Technology, that work is easier than ever.

In large-scale solar arrays, the challenge of finding active faults is often exacerbated by the difficulty of identifying string layouts with incomplete or outdated documentation. With a general understanding of your site's configuration, just a few connections, and non-contact tracing, the GFL-1500 enables technicians to identify the faulted branch and pinpoint the fault location within a string—without relying on detailed site maps or time-consuming test procedures. By combining multiple diagnostic functions into a single, easy-to-use system, the GFL-1500 delivers an unmatched ability to locate faults with non-contact signal tracing, making it an essential tool for high-efficiency solar maintenance and troubleshooting.

Ease-of-Use and Time Savings

The GFL-1500 is built to simplify solar ground fault detection in the field. From a central test location, technicians can begin tracing the fault path without repeatedly disconnecting conductors and brute-force testing each individual string. This streamlined approach saves valuable time and increases troubleshooting safety, enabling your team to solve problems quickly and confidently.

The GFL-1500 system includes both a signal tracing receiver and clamp, each suited to different stages of the diagnostic process. The clamp is especially useful for identifying the faulted combiner or string without making disconnections, even in noisy environments where signal clarity may be reduced. Once the affected solar string is identified, the signal tracing receiver or clamp can be used to precisely follow the fault path and pinpoint the issue within the string.

Designed for real-world conditions, the GFL-1500 is intuitive to operate, quick to deploy, and built for harsh environments, delivering an end-to-end troubleshooting solution that enables technicians to move efficiently from problem to resolution.





Integrated Diagnostic Function

Analyze Function

Quickly identifies the presence of an active fault and provides key diagnostic details, such as estimated location of the fault based on the number of modules in the string, estimated resistance range and voltage to ground, enabling technicians to assess system status before they start tracing.

Fault Tracing Function

Guides technicians along the fault path using real-time audio-visual signal feedback, allowing for accurate and efficient localization of the fault within the array.

Open Circuit Function

Helps technicians locate breaks in wiring within isolated strings by routing a traceable signal through the open circuit, giving technicians real-time audiovisual signal feedback to guide them directly to the point of interruption.

Mapping Function

Routes the traceable signal through a healthy string, allowing technicians to identify and confirm string layout, which is especially helpful in complex or undocumented arrays.

Safety and Compliance

As utility-scale PV systems increasingly adopt 1500 V DC architectures, the demand for safe, accurate, higher voltage-rated diagnostic tools continues to grow. High-voltage DC systems offer greater efficiency through longer strings and fewer components, but they also operate at voltages that require heightened safety awareness and specialized equipment for troubleshooting. The Fluke GFL-1500 system includes:

- Transmitter: CAT III 1500 V DC, CAT IV 600 V, meets the rigorous safety standards outlined in IEC 61010-1 and 61010-2-030.
- Receiver: CAT III 1500 V DC, CAT IV 600 V, meets IEC standard 61010-1.
- **Signal Tracing Clamp:** Rated for use on insulated conductors up to 1500 V.

Whether you're working at the inverter, combiner, or module level, the GFL-1500 Ground Fault Locator has been rigorously tested for safety and durability to provide a rugged, safe, fast, and reliable solution for identifying ground faults in high-voltage environments—empowering technicians to work confidently and efficiently in the field.



Specifications

General	Transmitter	Receiver	Clamp
Measurement category	CAT III 1500 \	/ DC / CAT IV 600 V	Not category rated. Use on insulated conductors only, up to 1500 V
Operating voltage	1500 V DC / 600 V AC		Non-contact. Use on insulated conductors only, up to 1500 V
Trace signal operating frequency	FAULT & MAP: 6.25 kHz OPEN: 32.764 kHz		N/A
Trace signal indications	Graphical display, audible beep	Numeric, bar graph display, audible beep, LED	AC current
Trace signal current output (typical)	FAULT & MAP: Array HIGH mode: 30 mA RMS Array LOW mode: 6 mA RMS Unit HIGH mode: 120 mA RMS OPEN: Unit HIGH mode: 100 mA RMS Unit LOW mode: 30 mA RMS	N/A	N/A
Trace signal voltage output - open circuit (typical)	FAULT & MAP: Unit HIGH mode: 30 V RMS OPEN: Unit HIGH mode: 30 V RMS Unit LOW mode: 25 V RMS	N/A	N/A
Voltage range / Resolution (ANALYZE)	Range: 0-1500 V DC Resolution: 1 V No voltage measurement if high capacitance & resistance detected	N/A	N/A
Resistance ranges (ANALYZE)	\approx <5 kΩ (FAULT) \approx 10 kΩ (FAULT) \approx 50 kΩ \approx 100 kΩ \approx 500 kΩ \approx >1 MΩ No resistance range if high capacitance & resistance detected	N/A	N/A
Range detection (typical)	N/A	FAULT & MAP: Array Mode Max distance via air: 4.75 m (15.6 ft) FAULT & MAP: Unit Mode Max distance via air: 5.9 m (19.4 ft) OPEN: Unit Mode Max (open air): 2.7 m (8.9 ft)	N/A
AC Current Measurement	Transmitter	Receiver	Clamp
Range	N/A	N/A	150 mA
Resolution	N/A	N/A	0.1 mA
Maximum conductor diameter	N/A	N/A	61 mm (2.4 in)



Specifications

-			
Display	Transmitter	Receiver	Clamp
Display type	Graphic LCD Display		Segment LCD Display
Illumination	Front light		Back light
Environmental specifications	Transmitter	Receiver	Clamp
Operating temperature	-20 °C to 50 °C	(-4 °F to 122 °F)	-10 °C to 50 °C (14 °F to 122 °F)
Operating Humidity) °C (32 °F to <86 °F)	90 %RH: 10 °C to <30°C (50 °F to <86 °F) 75 %RH: 30 °C to <40 °C
(non-condensing)) °C (86 °F to <104 °F) °C (104 °F to 122 °F)	(86 °F to <104 °F) 45 %RH: 40 °C to 50 °C
			(104 °F to 122 °F)
Operating Altitude	0 to 3 000 m (9 843 ft)		
Storage altitude	0 to 12 000 m (39 371 ft)		
Storage temperature and humidity (without batteries)	-20 °C to 70 °C (-4 °F	F to 158 °F), <95 %RH	-40 °C to 60 °C (-40 °F to 140 °F), <95 %RH
Transient protection	10.00 kV (1.2/50 μS surge)	N/A	N/A
Pollution degree		2	
IP rating	IP54 (Non-operating)	IP54	IP30 (Jaw Closed)
Drop test	1 m (3.28 ft)		
Mechanical and general specifications	Transmitter	Receiver	Clamp
Power supply	8 x AA IEC LR6 alkaline or NiMH rechargeable	4 x AA IEC LR6 alkaline or NiMH rechargeable	2 x AA IEC LR6 alkaline
Battery life (typical) No buzzer or front light	FAULT & MAP Array Mode: approx. 15 h FAULT & MAP Unit Mode: approx. 8 h OPEN Unit Mode: approx. 15 h	Approx. 16 h	>150 h (without backlight and spotlight)
Low battery indication		Yes	
Dimensions (L x W x H)	Approx. 244 x 180 x 106 mm (9.6 x 7.0 x 4.2 in)	Approx. 183 x 75 x 43 mm (7.2 x 2.95 x 1.69 in)	Approx. 257 x 116 x 46 mm (10.1 x 4.6 x 1.8 in)
Weight (batteries installed)	Approx. 2.04 kg (4.5 lb)	Approx. 0.27 kg (0.6 lb)	Approx. 0.6 kg (1.32 lb)







Test Lead Kit General Specifications

General specifications	
Includes	3x TL324 4mm to 4mm test leads (red, black, green),3x AC385 alligator clips (red, black, green), 2x TLPV1 MC4 to 4mm test leads (red, black)
Measurement category	CAT III 1500 V / CAT IV 1000 V (TL324 and AC385) CAT III 1500 V / CAT IV 600 V (TLPV1)
Operating current	30 A
Operating temperature	-20 °C to 50 °C (-4 °F to 122 °F)
Storage temperature	-20 °C to 70 °C (-4 °F to 158 °F)
	95 %RH: 10 °C to <30 °C (50 °F to <86 °F)
Operating and storage humidity	75 %RH: 30 °C to <40 °C (86 °F to <104 °F)
,	45 %RH: -20 °C to <10 °C or 40 °C to 50 °C (-4 °F to <50 °F or 104 °F to 122 °F), non-condensing
Operating altitude	3000 m (~9843 ft)
Storage altitude	12 000 m (~39 371 ft)
Pollution degree	2
Drop proof	1 m (3,28 ft)
Vibration	MIL-PRF-28800, class 2
Dimensions	TL324: 2 m (6.56 ft) AC385: approx. 93 x 52 x 21 mm (3.66 x 2.05 x 0.83 in), TLPV1: 1.5 m (4.92 ft)
Weight	Approx. 0.48 kg (1.06 lb)

Fluke Built, **Fluke Protected**

Reduce unplanned expenses and get the most out of your tools with Fluke Premium Care

When you invest in the best equipment in the industry, you want your money to go as far as possible. Fluke Premium Care provides coverage above and beyond your tool's original product warranty, so you don't need to worry about unexpected downtime caused by damaged test equipment, accessories, or tools in need of calibration or repair.

Choose Fluke Premium Care as a standalone plan or combine it with a product in a bundle, with flexible one-year or three-year term options.

	Standard Warranty	Premium Care
Repair manufacturing defects	Ø	
Accidental damage and repair		⊘
Replacement of damaged accessories		Ø
Annual calibration or performance check		
Expedited calibration and repair		
Priority tech support		②
Software updates		②
Expedited shipping		⊘



PremiumCare

Uptime Protection by FLUKE®

Learn more about Fluke Premium Care www.fluke.com/premiumcare



Ordering information

Model

Description

FLUKE-GFL-1500

1500 V Solar Ground Fault Locator.

Includes:

GFL-1500 Transmitter, GFL-1500 Receiver, GFL-1500 Clamp, MC4 Test Leads, 1500 V rated test leads, alligator clips, MC4 unlocking tool, soft carrying case, backpack style shoulder strap, AA Alkaline

batteries (14)

FLUKE-GFL-1500/FPC

FLUKE-GFL-1500 bundled with

FPC1S-GFL-1500-1 FPC3S-GFL-1500-1

plan for Fluke GFL-1500

1 year of Fluke Premium Care 1 year Fluke Premium Care

3 year Fluke Premium Care plan for Fluke GFL-1500

Complementary products

- TL324-RGB 1500 V rated test leads for the GFL-1500 Solar Ground Fault Locator
- AC385-RGB 1500 V rated alligator clips for use with TL324-RGB test leads
- 283 FC/PV 1500 V rated TRMS digital multimeter and wireless current clamp
- 393 FC 1500 V rated current clamp
- PVA-1500 PV Analyzer I-V Curve Tracer
- PRV240 Proving unit
- TLPV-UTOOL MC4 unlocking tool



Fluke. Keeping your world up and running.™